



## ELITE PREMIUM CLAD PAINT GUIDE

Color Name and Number		Base	Colorant	Gallon					
				OZ	48	96	192	384	
	White	Dutch Boy DW Maxbond Ext Acrylic Semi-Gloss	Ultra White DB831-07 (16)	AN Durable	-	2	-	1	1
				B Black	-	1	-	-	1
				L Raw Umber	-	4	-	1	1
	Almond	Dutch Boy DW Maxbond Ext Acrylic Semi-Gloss	Ultra White DB831-07 (16)	B Black	-	14	1	-	1
				C Yellow Ox	-	47	1	1	1
				L Raw Umber	2	31	-	-	1
	Cream	Dutch Boy DW Maxbond Ext Acrylic Semi-Gloss	Ultra White DB831-07 (16)	B Black	-	4	1	-	-
				C Yellow Ox	-	16	-	-	-
				L Raw Umber	-	4	-	-	1
	Taupe	Dutch Boy DW Maxbond Ext Acrylic Semi-Gloss	Light Base DB831-03 (16)	B Black	2	38	-	1	1
				C Yellow Ox	1	43	-	1	1
				F Red Oxide	-	12	-	-	-
				KW White	3	2	-	-	1
	Hunter Green	Dutch Boy DW Maxbond Ext Acrylic Semi-Gloss	Accent Base DB831-09 (16)	B Black	5	47	1	1	1
				C Yellow Ox	2	28	-	1	-
				D Phtalo G	4	3	1	-	-
				KX White	1	16	-	1	1
	Brown	Dutch Boy DW Maxbond Ext Acrylic Semi-Gloss	Accent Base DB831-09 (16)	AN Durable	2	8	-	1	1
				B Black	5	31	-	1	1
				F Red Oxide	-	42	1	-	1
				KX White	5	13	1	-	1
	Dark Bronze	Dutch Boy DW Maxbond Ext Acrylic Semi-Gloss	Accent Base DB831-09 (16)	B Black	7	36	-	1	-
				C Yellow Ox	3	9	1	-	-
				KX White	1	9	1	-	-
				VV HS Magen	1	40	1	-	1
	Charcoal Black	Dutch Boy DW Maxbond Ext Acrylic Semi-Gloss	Accent Base DB831-09 (16)	B Black	9	43	-	-	-
				C Yellow Ox	-	43	-	1	1
				KX White	3	5	1	1	-
				VV HS Magen	-	3	1	1	1
	Brick Red	Dutch Boy DW Maxbond Ext Acrylic Semi-Gloss	Accent Base DB831-09 (16)	B Black	1	21	1	1	-
				F Red Oxide	5	37	-	1	-
				KX White	4	35	1	-	-
				VV HS Magen	2	1	1	-	-
	Terra Bronze	Dutch Boy DW Maxbond Ext Acrylic Semi-Gloss	Accent Base DB831-09 (16)	B Black	3	20	-	-	1
				Y Yellow Ox	3	38	-	-	-
				KX White	5	22	-	1	-
				VV HS Magen	1	15	1	-	1
	Jet Black	Dutch Boy DW Maxbond Ext Acrylic Semi-Gloss	Accent Base DB831-09 (16)	B Black	9	3	1	1	-
				C Yellow Ox	-	11	-	1	1
				E Phthalo B	3	21	1	1	-
				VV HS Magen	1	11	-	1	-

### PAINT PROCESS

1. Sand raw wood with 180 grit sand paper and remove sanding dust.
2. Apply one coat white primer.
3. Lightly scuff / sand primer with 220 grit sand paper and remove sanding dust.
4. Apply top coat of Maxbond Satin or Semi-Gloss.